

Suitable for all types of fabrics

Does not alter colours

Active on all types of dirt

Liquid laundry detergent for manual and automatic washing of all kind of fabrics and all kind of dirt. Also active at low temperatures. Does not fade colours.

How to use

Pour the product into the washing machine reservoir or into the oaking tank of the fabrics for hand washing.

Laundry cleaner



Ed. 11/19

Technical data

ASPECT

Opaque liquid

PERFUME

Fresh

COLOR

White

TOTAL DRY RESIDUE [%]:

22 +/- 0,5

ACTIVE SUBSTANCE [%]:

24 +/- 0,5

PH: 8,7 +/- 0,5

DENSITY (G/ML): 1,045

VISCOSITY [cP]:

600 +/- 100

Dilution

20 - 30g / Kg of dry fabric

Pictograms



DANGER



Warnings

Causes skin irritation. Causes serious eye damage. Wash hands thoroughly after handling. Wear protective gloves and eye protection. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER or doctor/physician. If skin irritation occurs: Get medical advice/attention. Take off contaminated clothing and wash it before reuse. Contents ALKYL ETHER SULFATE C12 - 14, SODIUM SALT, ALKYL POLYGLYCOL ETHER C12 - 18.

Notes

Packaging

CODE	SIZE	QUANTITY	PALLET	EAN
6848	5 Kg	4	9X4	Product 8001990068485 Box 08001990268489



info.en@suttereasy.com

www.suttereasy.com